



# Understanding SlatWall MX™ Strip Load Capacity




SlatWall MX™ Strip can hold a 75 lbs point load hanging at a 6" distance from the slatwall face:

- *At maximum loading, adjacent load points within the same groove must be spaced 16" apart minimum*
- *At maximum loading, load points must be spaced 8" minimum from the ends*



If the 75 lbs load moves further away than 6" from the slatwall face, the slatwall could break



If the load increases to more than 75 lbs, the slatwall could break