



Understanding SlatWall MX® Strip Load Capacity




SlatWall MX® Strip can hold a 75 lbs point load hanging at a 6" distance from the slatwall face:

- At maximum loading, adjacent load points within the same groove must be spaced 6" apart minimum
- At maximum loading, the outer most load points must be positioned inside the outer most mounting points



If the 75 lbs load moves further away than 6" from the slatwall face, the slatwall could break



If the load increases to more than 75 lbs, the slatwall could break