


# Instructions

## Contents




Crown Molding MX™



Crown Molding MX™  
P/N: HCMLL.X

## Installation Instructions



1. For best cutting results on aluminum, use saw blades designed to cut 1/16" thick metal (also known as "sheet metal").
2. For best cutting results on stainless steel, use a low speed saw and use a saw blade designed to cut 1/16" thick metal (also known as "sheet metal").
3. Attach to wall with fastener of choice (nails, dry wall screws, etc)
4. Drill appropriate size holes into Crown molding and fasten to wall

Any questions or problems, please contact us:

Gupta Permold Corporation  
Consumer Goods Division  
diamondLife™ Brand  
234 Lott Road  
Pittsburgh, PA 15235  
USA  
Ph. 412.793.3511 x103  
Fx. 412.793.1055  
Email. [help@diamondlifegear.com](mailto:help@diamondlifegear.com)  
Store. [diamondlifegear.com](http://diamondlifegear.com)



Find hundreds of more great work space enhancement products at [www.diamondlifegear.com](http://www.diamondlifegear.com)

Doing a common thing uncommonly well, brings success.

Welcome to the diamondLife.™

## Accessories



Crown Molding MX™ Inside Corner  
P/N: HCMIC



Crown Molding MX™ Outside Corner  
P/N: HCMOC



### Helpful Hint!

Remove protective plastic film after installation